

UPS Topology	UPS Range / Model	RS232	USB	Network-MS	Modbus-MS	Relay-MS	ConnectUPS-BD ConnectUPS-X Slot	PXG-MS	PXGX UPS or PXGX 2000 (legacy)	IRC-MS	PW Relay Card.	Software for Protection		Software for Supervision	
												UPS Companion	IPP	IPM	
												1.04	1.53	1.60	
Off-Line	Eaton Ellipse ECO	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Protection Center	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Protection Station	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Eaton 3S	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
Line Interactive	Eaton Ellipse MAX	✓	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Eaton 5E	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Eaton 5S	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Eaton Ellipse Pro	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Nova AVR	X	✓	X	X	X	X	X	X	X	X	✓	X	X	
	Eaton 5110	X	✓	X	X	X	X	X	X	X	X	X	✓	✓	
	Eaton 5115 and 5115 RM	X	✓	X	X	X	✓	X	X	X	✓	X	✓	✓	
	Eaton 5130	✓	✓	✓	X	✓	X	X	X	X	X	X	X	✓	✓
	Eaton Evolution and Evolution S	✓	✓	✓	X	✓	X	X	X	X	X	X	X	✓	✓
	Eaton 5SC Tower	✓	✓	X	X	X	X	X	X	X	X	X	X	✓	X
	Eaton 5SC Rack	✓	✓	✓	X	✓	X	X	X	X	X	X	X	✓	✓
	Eaton 5P	✓	✓	✓	X	✓	X	X	X	X	X	X	X	✓	✓
Eaton 5PX	✓	✓	✓	✓	✓	X	X	X	X	X	X	X	✓	✓	
On Line	Eaton EX (from 700 to 3kVA)	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton EX RT Mini-Slot	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton MX / MX Frame	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton 9130	✓	✓	✓	✓	X	✓	X	X	X	✓	X	✓	✓	
	Eaton 9140	✓	✓	✓	✓	X	✓	X	X	X	✓	X	✓	✓	
	Eaton 9135	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton 9170+	✓	✓	✓	✓	X	X	X	X	X	X	X	✓	✓	
	Eaton 9E	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton 9PX/SX	✓	✓	✓	✓	✓	X	X	X	X	X	X	✓	✓	
	Eaton 9PM	✓	X	✓	✓	X	X	X	X	X	X	X	✓	✓	
Three Phase	Blade UPS	X	X	X	X	X	✓	X	✓	X	✓	X	✓	✓	
	Eaton 9355/9155	X	X	X	X	X	✓	X	✓	X	✓	X	✓	✓	
	Eaton 93PM	X	X	✓	X	X	X	✓	X	✓	X	X	✓ (*)	✓ (*)	
	Eaton 93PS	X	X	✓	X	X	X	✓	X	✓	X	X	✓ (*)	✓ (*)	
	Eaton 93E	X	X	✓	✓	X	X	X	X	✓	X	X	✓	✓	
	Eaton 9390	X	X	X	X	X	✓	X	✓	X	✓	X	✓	✓	
	Eaton Power Xpert 9395	X	X	X	X	X	✓	X	✓	X	✓	X	✓	✓	

(*) Require Network-MS card to get sensor alarms