

UPS and Connectivity Compatibility List

January 10, 2019

| UPS Topology | UPS Range / Model | RS232 | USB | Network-MS | Network-M2 | Modbus-MS | Relay-MS | ConnectUPS-BD ConnectUPS-X Slot | PXG- MS | PXGX UPS or PXGX 2000 (legacy) | IRC-MS | PW Relay Card. | Software for Protection | | Software for Supervision | |
|------------------|---------------------------------|-------|-----|------------|------------|-----------|----------|------------------------------------|---------|-----------------------------------|--------|----------------|-------------------------|------|--------------------------|---|
| | | | | | | | | | | | | | UPS Companion | IPP | IPM | |
| | | | | | | | | | | | | | 1.04 | 1.61 | 1.64 | |
| Off-Line | Eaton Ellipse ECO | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Protection Center | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Protection Station | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Eaton 3S | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| Line Interactive | Eaton Ellipse MAX | ✓ | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Eaton 5E | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Eaton 5S | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Eaton Ellipse Pro | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Nova AVR | X | ✓ | X | X | X | X | X | X | X | X | X | ✓ | X | X | |
| | Eaton 5110 | X | ✓ | X | X | X | X | X | X | X | X | X | X | ✓ | ✓ | ✓ |
| | Eaton 5115 and 5115 RM | X | ✓ | X | X | X | X | ✓ | X | X | X | X | ✓ | X | ✓ | ✓ |
| | Eaton 5130 | ✓ | ✓ | ✓ | X | X | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton Evolution and Evolution S | ✓ | ✓ | ✓ | X | X | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 5SC Tower | ✓ | ✓ | X | X | X | X | X | X | X | X | X | X | X | ✓ | X |
| | Eaton 5SC Rack | ✓ | ✓ | ✓ | ✓ | X | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 5P | ✓ | ✓ | ✓ | ✓ | X | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| Eaton 5PX | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | X | X | X | X | X | X | X | ✓ | ✓ | |
| On Line | Eaton EX (from 700 to 3kVA) | ✓ | ✓ | ✓ | X | ✓ | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton EX RT Mini-Slot | ✓ | ✓ | ✓ | X | ✓ | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton MX / MX Frame | ✓ | ✓ | ✓ | X | ✓ | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 9130 | ✓ | ✓ | ✓ | X | ✓ | X | ✓ | X | X | X | ✓ | X | ✓ | ✓ | ✓ |
| | Eaton 9140 | ✓ | ✓ | ✓ | X | ✓ | X | ✓ | X | X | X | ✓ | X | ✓ | ✓ | ✓ |
| | Eaton 9135 | ✓ | ✓ | ✓ | X | ✓ | ✓ | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 9170+ | ✓ | ✓ | ✓ | X | ✓ | X | X | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 9E | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | X | X | X | X | X | X | ✓ | ✓ |
| | Eaton 9PX/SX | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | X | X | X | X | X | X | ✓ | ✓ |
| Eaton 9PM | ✓ | X | ✓ | X | ✓ | X | X | X | X | X | X | X | X | ✓ | ✓ | |
| Three Phase | Blade UPS | X | X | X | X | X | X | ✓ | X | ✓ | X | ✓ | X | ✓ | ✓ | ✓ |
| | Eaton 9355/9155 | X | X | X | X | X | X | ✓ | X | ✓ | X | ✓ | X | ✓ | ✓ | ✓ |
| | Eaton 93PM | X | X | ✓ | X | X | X | X | ✓ | X | ✓ | X | X | ✓ | ✓ | ✓ |
| | Eaton 93PS | X | X | ✓ | X | X | X | X | ✓ | X | ✓ | X | X | ✓ | ✓ | ✓ |
| | Eaton 93E | X | X | ✓ | X | ✓ | X | X | X | X | ✓ | X | X | ✓ | ✓ | ✓ |
| | Eaton 9390 | X | X | X | X | X | X | ✓ | X | ✓ | X | ✓ | X | ✓ | ✓ | ✓ |
| | Eaton Power Xpert 9395 | X | X | X | X | X | X | ✓ | X | ✓ | X | ✓ | X | ✓ | ✓ | ✓ |

(*) Require Network-MS card to get sensor alarms